

# SNAPGRID<sup>®</sup> for ARRI<sup>®</sup> SKYPANEL<sup>®</sup> SNAPBAG<sup>®</sup> S120, S60 and S30

Please also refer to the luminaire instructions regarding use of accessories.

L2.0010381 SGA120SB40

L2.0008143 SGA60SB40

L2.0008140 SGA30SB40



Open the SNAPGRID<sup>®</sup> and attach it with the hook and loop into the SNAPBAG<sup>®</sup>.

## MOUNTING POINT FOR THE SAFETY CABLE

Always secure the accessory with a suitable safety cable from falling when the primary mounting method fails.



Read also our additional safety & handling instructions:  
[www.dopchoice.com/instruction](http://www.dopchoice.com/instruction)

# SNAPGRID<sup>®</sup> for ARRI<sup>®</sup> SKYPANEL<sup>®</sup> S120, S60 and S30

Please also refer to the luminaire instructions regarding use of accessories.

L2.0010382 SGA120P4060

L2.0008144 SGA60P40

L2.0008142 SGA30P40



**MOUNTING POINT FOR THE SAFETY CABLE**  
Always secure the accessory with a suitable safety cable from falling when the primary mounting method fails.



**Pull the elastics on all 4 corners over the 4 blue blocks.**

**Read also our additional safety & handling instructions:  
[www.dopchoice.com/instruction](http://www.dopchoice.com/instruction)**